

Ⓓ Aufbauanleitung

Ⓕ Notice de montage

Ⓖ Handleiding voor de montage

Ⓒ Montážní návod

Ⓗ Szerelési útmutató

Ⓓ Montaj talimatları

Ⓖ Assembly instruction

Ⓙ Istruzioni di montaggio







Ⓗ Instrukcja montażu

Ⓒ Navod na montaž

Ⓙ Instrucțiuni de montaj

Ⓙ Инструкция по монтажу

36-1006-82-000



0
10
20
30
40
50
60
70
80
90
100
110
120
130
140
150
160

Service
Serwis



Dienstverlening
Servis

Dienst kaart
Сервисная служба



Name • Naam • Naam • Isim • Название

Nr. • No. • Номер


Typ • Type • Тип • Тип




A	006110-82	x2
B	006210-32	x2
C	149312-32	x2
D	149410-32	x2
E	006510-52	x4
F	149311-32	x2



6





13




14


1-000001=



17




18




19

		mm	
6	1-000013-00	8x40	x12
13	1-000117-07	D=28	x8
14	1-000091-07	3x16	x16
17	1-000046-07	L34	x8
18	1-000048-07	15x12	x8
19	1-000057-57	3,5x40	x8


1.



2.



3.



4.

